



---

<i>REF.</i>	<i>PART NAME</i>	<i>PART NO.</i>	<i>QTY.</i>
1	Fuel Pump Assembly	1-31-003	1
2	Sender	94460-02000	1
3	Packing (Fuel)	31115-02000	1
4	Fuel Cut Valve	31190-02000	1
5	Screw (Valve)	12431-03081	1
6	Fuel Pump	31119-02000	1
7	Cup Assembly	940013	1
8	Packing (Valve)	31191-02010	1
9	Plate (Fuel)	31116-02000	1
10	Screws	774211	6
11	Washer, Fuel Pump Seal	774182	6
12	Fuel Tank Assembly	1-31-001	1
13	Fuel Tank	1-31-100	1



<i>REF.</i>	<i>PART NAME</i>	<i>PART NO.</i>	<i>QTY.</i>
1	Accelerator Pedal	1-31-211	1
2	Tread, Accelerator	414004	1
3	Arm, Accelerator	1-31-212	1
4	Accelerator Mount	1-31-200	1
5	Pin	773412	3
6	Cotter Pin	771699	3
7	Flange Bolt	771035	2
8	Flange Nut	771036	2
9	Tie Strap	772273	1
10	Throttle Cable	1-31-213	1
11	Throttle Cable Assembly	1-31-005	1



<i>REF.</i>	<i>PART NAME</i>	<i>PART NO.</i>	<i>QTY.</i>
1	Filter	31911-02100	1
2	Fill Neck Assembly	31040-02000	1
3	Fuel Vapour Tube (gray)	31340-02000	1
4	Fuel Vapour Tube (green)	31330-02000	1
5	Fuel Feed Tube (blue)	31310-02000	1
6	Fuel Line, Purge	31342-02000	1
7	Support Tube Clamp	31326-02000	4
8	Fuel Tube Clip	31335-02000	4
9	Canister	31420-02000	1
10	Fuel Filter Line	31311-02000	1