


<i>REF.</i>	<i>PART NAME</i>	<i>PART NO.</i>	<i>QTY.</i>
1	Transmission	45000-02730	1
2	Transmission Pan	45281-02700	1
3	Filter	46321-02000	1
4	ATM Cable Assy.	46760-02100	1
5	Shifter Sub Assy.	1-43-200	1
6	Shifter Mount	1-43-211	1
7	Flat Lock Nut	770819	2
8	Hex Head Bolt	771951	2
9	Flange Lock Nut	771036	4
10	Hex Head Bolt	771035	4
11	Bracket Transmission	45262-02700	1
12	Speed Sensor Assy.	46524-02700	1
13	Oil Level Gauge (Transmission)	45291-02700	1
	Clip, ATM Cable Assy. (not shown)	43796-36700	1



7 →

Boot Kit – Wheel Side
Clip
Boot
Bands
Ring Snap
Grease

6 →

Boot Kit – Differential Side
Clip
Boot
Bands
Ring Snap
Grease

<i>REF.</i>	<i>PART NAME</i>	<i>PART NO.</i>	<i>QTY.</i>
1	Shaft, RH Drive	49500-02410X	1
2	Shaft, LH Drive	49500-02400X	1
3	Cotter Pin	14300-04351	2
4	Slotted Axle Nut	49551-21000	2
5	Washer, Axle	49549-21000	2
6	Boot Kit, Differential Side	49506-02A00	2
7	Boot Kit, Wheel Side	49509-02A00	2